

For safe car ownership

When you buy a secondhand car, you can choose to get a warranty from the dealer. This warranty helps if certain parts of the car break unexpectedly. AutoConcept provides warranties to cover repair expenses for cars. Our warranties have different levels of coverage and are made to suit most types of vehicles.



XtraGaranti Guld/Gold

- Covers most components in modern cars.
- Maximum compensation per damage is 60,000 SEK incl. VAT.
- Transitions to Silver if the car reaches an age of 9 years or 150,000 km within the warranty period.

XtraGaranti Silver

- Covers many of the car's essential components.
- Maximum compensation per damage is 50,000 SEK incl. VAT.
- Transitions to Bronze if the car reaches an age of 11 years or 180,000 km within the warranty period.

XtraGaranti Brons/Bronze

- Good protection for older cars
- Maximum compensation per damage is 35,000 SEK incl. VAT
- Transitions to Base if the car reaches an age of 15 years or 200,000 km within the warranty period.

XtraGaranti Bas/Base

- Basic protection for older cars
- Maximum compensation per damage is 25,000 SEK incl. VAT
- Expires when the car reaches an age of 20 years or 300,000 km within the warranty period.

Add-on products

Upgrade your warranty with one of our add-on products for an even more stress-free ownership experience.

[RoadAssist](#)

[RentalCar](#)

[Battery](#) (Only available as an option for Gold)

[ExcessWaiver](#)

Product details

XtraGaranti Guld/Gold

The maximum compensation per damage for XtraGaranti Gold is 60,000 SEK including VAT. XtraGaranti Gold transitions to XtraGaranti Silver if the vehicle reaches an age of 9 years or 150,000 km within the warranty period.

1. Front/Rear Differential:
All electrical and mechanical components.

2. Engine electronics:
All electrical and mechanical components.

3. Oil leakage:
When the oil leak requires disassembly of the engineblock, gearbox or cylinder head.

4. Engine:
All electrical and mechanical components.

5. Cooling system:
All electrical and mechanical components.

6. Fuel system:
All electrical and mechanical components.

7. Transmission/Gearbox:
All electrical and mechanical components.

8. Brake system:
All electrical and mechanical components.

9. Drive shafts:
All electrical and mechanical components.

10. Suspension:
All electrical and mechanical components.

11. Clutch:
All electrical and mechanical components.

12. Electrical Components:
All electrical and mechanical components.

13. Air Conditioning:
All electrical and mechanical components.

14. Turbocharger/Supercharger:
All electrical and mechanical components.

15. Steering system:
All electrical and mechanical components.

16. Safety:
All electrical and mechanical components.

17. Other:
Oil, coolant, refrigerant or similar that needs to be replaced in connection with an approved repair.

Considering an electric or hybrid car?



For electric/hybrid cars, you can choose a smart add-on that covers the high-voltage battery.

XtraGaranti Silver

The maximum compensation per damage for XtraGaranti Silver is 50,000 SEK including VAT. XtraGaranti Silver transitions to XtraGaranti Bronze if the vehicle reaches an age of 11 years or 180,000 km within the warranty period.

1. Engine:
Engine block, cylinder head, all internal electrical and mechanical components in these incl. cylinder head gasket. All electric motors for propulsion.

2. Clutch:
Master cylinder, slave cylinder, pressure plate, release bearing, and clutch disc (not wear).

3. Transmission:
All internal electrical and mechanical components, including transmission control unit and gear robots.

4. Drive shafts:
Driveshaft, universal joints, and CV joints.

5. Four-wheel drive:
All internal electrical and mechanical components in the distribution gearbox.

6. Front/Rear Differential:
All internal electrical and mechanical components in the (final) end drive and differential.

7. Converter:
All internal electrical and mechanical components in the converter.

8. Engine electronics:
Engine control module, starter, alternator, ignition cassette, ignition coil, engine temperature sensor, oil temperature sensor, speed sensor, camshaft sensors and crankshaft sensor. ECU for electric propulsion motors, DC/AC inverter, and DC/DC converter.

9. Steering system:
Steering rack, steering box, steering pump, and the steering column.

10. Fuel system:
Fuel control unit, fuel pump, throttle body, injectors, air mass meter, oxygen sensor, EGR valve and fuel level sensor.

11. Brake system:
Servo pump, brake booster, master cylinder, wheel cylinders/brake callipers, ABS control unit and the ABS hydraulic unit.

12. Wheel suspension:
Coil spring, torsion bar and shock absorber.

13. Electrical Components:
Control unit for central locking, tachometer, speedometer, fuel gauge, engine temperature gauge, horn, wiper motor, washer motor, window lift motor and cruise control.

14. Turbocharger/Supercharger:
All electrical and mechanical components in the turbo and supercharger incl. turbo control unit and the boost pressure sensor.

15. Air Conditioning:
Compressor, control unit, magnetic clutch and thermostat.

16. Cooling system:
Water pump, oil cooler, thermostat, expansion tank, thermal contact, temperature sensor, and viscous fan clutch.

17. Safety:
Belt tensioners, airbags, and control unit for airbag system.

18. Other:
Oil, coolant, refrigerant or similar that needs to be replaced in connection with an approved repair.

XtraGaranti Brons/Bronze

The maximum compensation per damage for XtraGaranti Bronze is 35,000 SEK including VAT. XtraGaranti Bronze transitions to XtraGaranti Basic if the vehicle reaches an age of 15 years or 200,000 km within the warranty period.

1. Engine:
Engine block, cylinder head, all internal electrical and mechanical components in these incl. cylinder head gaskets. All electric motors for propulsion.

2. Engine electronics:
Engine control module, starter and alternator. ECU for electric propulsion motors.

3. Cooling system:
Water pump.

4. Transmission:
All internal electrical and mechanical components in the transmission.

5. Four-wheel drive:
All internal electrical and mechanical components in the distribution gearbox.

6. Clutch:
Master cylinder, slave cylinder, pressure plate, release bearing, and clutch disc (not wear).

7. Steering system:
Power steering pump.

8. Brake system:
Servo pump.

9. Fuel system:
Fuel pump.

10. Front/Rear Differential:
All internal electrical and mechanical components in the (final) end drive and differential.

11. Other:
Oil, coolant or similar that needs to be replaced in connection with an approved repair.

XtraGaranti Bas/Base

The maximum compensation per damage for XtraGaranti Basic is 25,000 SEK including VAT. XtraGaranti Base ceases when the vehicle reaches an age of 20 years or 300,000 km within the warranty period

1. Engine:
Engine block, cylinder head, all internal electrical and mechanical components in these incl. cylinder head gaskets. All electric motors for propulsion.

2. Transmission:
All internal mechanical components in the transmission.

3. Four-wheel drive:
Internal mechanical components in the distribution gearbox.

4. Front/Rear Differential:
All internal mechanical components in the (final) end drive and differential.

5. Other:
Oil, coolant or similar that needs to be replaced in connection with an approved repair.

Important

The warranty only applies to the components listed in the warranty certificate and where the function has suddenly and unexpectedly ceased.

Unless otherwise stated in the warranty certificate, the following are not covered: bodywork, interior details, paint, glass, catalytic converter, noises, filters, lamps, batteries, entertainment/navigation/communication equipment, programming, software updates, leaks, wiring, hoses, cables, pipes, belts, wear and tear, high oil consumption, and parts normally included in maintenance service. Nor are ancillary costs such as rental cars, taxis, hotels, or similar covered.

Maximum age or mileage

If your car reaches the age or the mileage limit within the warranty period, it will still be protected. The warranty then transitions to a warranty with lower coverage

In case of damage

Please wait for approval from AutoConcept before starting any repairs on your car. If you go ahead without approval, you might end up having to cover the repair costs yourself.

Warranty extension

Before your warranty runs out, you'll get a chance to extend it. It's a great way to keep protecting your car and avoid expensive repairs.

About AutoConcept

AutoConcept was founded in 1999. Today, over 20 years later, we operate throughout the Nordic region, and many thousands of vehicle owners have realized that owning a used vehicle can be as secure as owning a new one if you choose AutoConcept.